VIDEO SOUND BAR

User Manual V1.0



COPYRIGHT INFORMATION

Copying, reproducing or transmitting this file is not allowed if a license is not provided by our company. Unless copying this file is for the purpose of backup after purchasing this product.

■ In order to keep improving the product. Our company reserves the right to make changes to product specifications without prior notice. The information in this file is subject to change without prior notice.

To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.

Disclaimer of warranties: Our company is neither responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.

SYMBOLS INSTRUCTION

Symbol	Instructions	
Explanation	To represent the supplement and explanation of the text.	
🛱 Note	To indicate that the user is alerted to some important operation or to prevent the potential danger of injury and property damage.	
Marning	To indicate a potential risk that, if not avoided, may result in injury accidents, equipment damage or business interruption.	
⚠ Dangerous	To indicate a high potential risk that, if not avoided, may result in significant risk of death or injury.	

SAFETY NOTES

The following important notes must be followed carefully to run the camera and respective accessories in total safety. The camera and relative accessories are called video system in this section.

- Before installing the camera, please read this manual carefully. Please follow installation instructions indicated in this manual during installation. Please keep this manual for future use.
- Please put the power cable, video cable and control cable in safe place.
- Do not operate the camera beyond the specified temperature and humidity. Working temperature range of the camera is between 0°C ~ + 40°C. The ambient humidity range is 10%RH ~ 90%RH.
- During transporting, avoid violent shake or force to the camera.

CONTENTS

1.	ABOUT THE PRODUCT	1
1.1	. FEATURE	1
1.2	. APPLICATION SCENARIOS	1
2.	COMPONENTS	2
2.1	ACCESSORIES	2
2.2	. MAIN PARTS & INTERFACES	3
2.3	. REMOTE & CONTROL(STANDARD)	4
2.4	. COMMON FUNCTION	5
3.	INSTALLATION	6
3.1	. DIMENSION FIGURE	6
3.2	. INSTALLATION	7
3.3	. CONNECTION	9
4.	MENU 1	0
4.1	. MENU STRUCTURE1	0
4.2	. MENU FUNCTION INSTRUCTIONS1	1
5.	TECHNICAL DATA 14	4
6.	AFTER-SALES SERVICE 1	6

1. ABOUT THE PRODUCT

1.1.Feature

- Designed with built-in all-in-one camera, microphone, and speaker;
- With Speaker Tracking Function and Auto Framing Tracking Function;
- 110° ultra-wide FOV with no distortion, full coverage of the whole meeting room;
- 4K Ultra HD video @30fps, brings super clear video experience;
- EPTZ realizes automatic viewfinder and intelligently selects all participants;
- Effective and accurate speaker detection and tracking function, fast and accurate close-up of speakers;
- Built-in high-sensitive omnidirectional microphone, up to 5 meters of sound pickup distance, supports ANS, AEC, AGC;
- USB 3.0, MJPEG/H.264/H.265;
- Supports UVC/UAC protocol;
- Configure mute and mute prompt functions;
- Supports Bluetooth and USB connection (can not work together);
- Exquisite remote control settings, easy to hold and control.

1.2.Application Scenarios



2. COMPONENTS

2.1.Accessories

When you open the box, check all accessories according to the packing list.



2.2.Main Parts & Interfaces



		- 	0
3	4567	8	

Bottom View

No.	Interface/ Component	No.	Interface/ Component
1	LED Light	5	Ethernet
2	Camera Lens	6	EXT(connect with external microphone)
3	Bracket	7	Power(DC12V)
4	USB Type B	8	Service

2.3.Remote & Control(Standard)



No.	Name	Function	
1	Privacy	Turn on / off privacy protection	
2	Auto Framing	Turn on / off Auto framing	
3	Pan	 In menu mode, set menu options In non-menu mode, pan right / left 	
4	Volume	Increase / decrease volume	
5	Menu	Open / close the OSD menu	
6	Mute	Turn on / off the microphone sound	
7	Speaker Tracking	Turn on / off the speaker tracking	
8	Tilt	 In menu mode, set menu options In non-menu mode, tilt up / down 	
9	HOME	 In menu mode, confirm to Enter In non-menu mode, press to move camera to Home position Long press Home button to switch between USB and Bluetooth audio 	
10	Zoom	Zoom in / out	
11	Number	 Short press to CALL saved preset Long press(2 seconds) to set preset 	

2.4.Common Function

2.4.1. EPTZ

The camera supports EPTZ control, and 4x digital zoom. The EPTZ can be controlled via direction keys to adjust the image position. And the current image size can be adjusted via zoom button.

Note: the Pan / Tile button can not work under the max FOV.

2.4.2. Auto Framing

This product has auto framing function. Press the corresponding key and the camera screen can be intelligently scaled according to the number of people in the meeting scene, and centralize all participants. Press again to turn off the auto framing.

Note: the auto framing state will be ended by press PTZ buttons, Auto Framing button or call the saved presets.

2.4.3. Speaker Tracking

The all-in-one supports Speaker Tracking function. Press the Speaker Tracking button to turn on / off the Speaker Tracking function. The all-in-one will give the person who is speaking a close-up view under the Speaker Tracking ON state.

2.4.4. Set/Call The Preset

Long press (2 seconds) the number buttons to set preset;

Short press the number buttons to CALL saved preset, and the camera will quickly go to saved preset position.

2.4.5. Menu Function

After entering the menu, select the menu options via direction keys.

Press the HOME key to enter the options, adjust the options by using the pan button.

Press the Menu key to return to previous menu until the exit menu.

2.4.6. Built-in USB to network adapter

The all-in-one has a built-in USB network adapter. After connecting the network cable to the camera, the computer connect to the camera can access the network through the USB cable without connecting other network cables. Only one USB cable can realize the synchronous transmission of audio, video and network, eliminating the trouble of multiple wiring.

2.4.7. USB And Bluetooth Switching Instructions

After the camera is connected to the USB cable and powered on, the default is USB mode. Long press the HOME key for 2 seconds, the sound source of the horn is switched to Bluetooth, and the word "BT" is displayed on the screen for 5 seconds. Bluetooth is visible and automatically connected to the device (pairing connection is required for the first time).Bluetooth name: 4K Tracking Soundbar.

In Bluetooth mode, long press the HOME key for 2 seconds, the Bluetooth is disconnected, the screen displays the word "USB" for 5 seconds, the sound source of the speaker is switched to USB, and the Bluetooth is invisible and cannot be connected.

2.4.8. Indicator

Action	Indicator Status
Power on, video disable	Green
Power on, video enable	Blue
Mic Mute	Red
Adjust The Volume	Green, the range of light on varies with the volume

3. INSTALLATION

3.1.Dimension Figure

Front



Bottom



3.2.Installation

3.2.1. Bracket(Standard)



1. If your TV doesn't have mounting bracket, please fix the mount bars with screw holes on the back of your TV.



2. If your TV has a mounting bracket, please fix the mount bars with screw holes on the mounting bracket.



3.2.2. Wall-mount

1. Referring to the aperture and position of the mounting hole, drill the corresponding hole at the mounting place and fix the bracket in the mounting place with screws.



2. Insert the camera base into the groove of the bracket. To ensure the safety of the camera, make sure the camera is firmly attached to the bracket before you let it go.



3.3.Connection



Bluetooth Connection:



4. MENU

4.1. Menu Structure

<image/>		ON, OFF
	— BRIGHTNESS	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
	— CONTRAST	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
	— HUE	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
	- SATURATION	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
	- SHARPNESS	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15
	— GAMMA	0, 1, 2, 3, 4
	— GAIN	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
	— ANTI FLICKER	50Hz, 60Hz
	BACKLIGHT	ON, OFF
	COMP.	



4.2. Menu function instructions

- 1. Press the menu key on the remote control to enter the menu.
- Press the up / down / left / right buttons of the remote control to select the menu option.
 When the font of the option is enlarged, it means that the option has been selected. Press the home key to access the selected menu.
- 3. Use the left and right buttons of the remote control to change the setting value.

Menu	Options	Function Descriptions
	Brightness	Adjust the brightness of the image.
	Contrast	Refers to the ratio between the brightest and darkest areas of the image. The greater the ratio, the more gradation levels from black to white will be, thus the richer the color performance, the clearer the image is.
	Hue	Adjust the overall color of the image.
	Saturation	Refers to the purity and brightness of image color, the higher the saturation, the color effect is bright and beautiful.
	Sharpness	Adjust the sharpness of image and image edge sharpness. The higher this number is, the more contrast the detail in the plane of the image will be, making it look clearer.
	Gamma	Adjust the permeability of the image.
	Gain	Adjust the light sensitivity.
	Anti Flicker	Prevent image flickering when working in an env-ironment with refresh rates that are inconsistent with the power supply system.
	Backlight Comp.	The camera lens can automatically compensate for the brightness of darker targets in the strong light background.
	Language	Switch between English or Chinese.
	Mirror	The camera image is turned 180 ° horizontally.
System	Flip Dzoomlimit Expert Mode	The camera image flips 180 ° vertically.
Jystelli		Set the digital magnification.
		Start this mode to display the OSD box of the selected target in the image.
	Detection Sens.	Adjust detection sensitivity of automatic frame.

	Framing Move Sens.	Set automatic frame selection and screen movement sensitivity.
	Target Lost Act.	The camera action when the auto framing target is lost. Keep the original position or take a panoramic view, or automatically adjust to the set preset point.
	Auto Framing	When choosing "ON", the camera will be zoom in / out to center all participants in the picture, according to the conference scene.
	Speaker Tracking	Turn on/off the sound source positioning function.
	Active Audio	Switch between USB or Bluetooth mode.
	IR Address	Address when the remote control controls the camera.
Device Info	Image Version	The version number of the image software.
	Audio Version	The version number of the audio software.

5. TECHNICAL DATA

Camera		
Image Sensor	1/2.8" 4K CMOS, 8.46MP	
IRIS	F2.2	
Focal Lens	f=2.1mm	
Digital Zoom	4X	
Field of View	Horizontal: 110°, Vertical: 74°	
EPTZ	Support	
Min Focus Distance	50cm	
Min Illumination	50Lux	
Exposure	Auto, Manual, Shutter Priority	
White Balance	Auto, Manual	
Digital Noise Reduction	2D, 3D	
Image Flip	Flip, Mirror	
Audio		
Built-in Mic	4MIC array	
Pick-up Distance	5meter	
Audio Process	ANS, AEC, AGC	
Speaker	Support	
Interface		
	1 channel USB3.0, Type B;	
	1. support UVC 1.0	
	2. support MJPEG/H.264/H.265	
	1) MJPEG: 4K@30fps, 1920x1080@30/25fps,	
	1280x720@30/25fps	
USB	2) H.264: 4K@20fps, 1920x1080@30/25fps,	
	1280x720@30/25fps	
	3) H.265: 4K@20fps, 1920x1080@30/25fps,	
	1280x720@30/25fps	
	3. support UAC	
Network	1 channel RJ-45, 10/100/1000M	

Mic-Extension	Support
Bluetooth	Support
Remote-Control	Support
Power	DC 12V
General	
Consumption	< 8W
Working Temperature	0°C ~ + 40°C
Storage Temperature	-20°C ~ +60°C
Working Humidity	10%RH ~ 90%RH
Storage Humidity	10%RH ~ 95%RH
Dimension (L×W×H)	603mm×74mm×95mm
Net Weight	1.66kg
Color	Black

6. After-sales service

Dear users, in order to ensure that you fully enjoy the quality service, please carefully read the following product and service charter.

The company provides limited warranty and lifetime maintenance services

1. The limited warranty period is 12 months from the date of shipment. During the limited warranty period, you will enjoy the free service of the product, which will be sent by the user or sent to the company for repair (improper use, man-made or irresistible of the failure, does not belong to the warranty).

2. More than 12 months of the limited warranty period, the product failure to implement paid maintenance services.

Maintenance response time

1. The user will send the product to the company and received, 24 hours response service.

2. Users back the product to my company before, please contact with the related person of our company in advance, and then send the product back to my company. Otherwise there is no maintenance of the situation, the user is responsible for their own.

This user manual is only for reference. It is subject to change. Please ask for the latest version from your supplier.

CA/YF- AMCG309UV2-ZD-011

Y06020711010