7" 12G-SDI Field Monitor



User Manual

Foreword

Thank you for purchasing our 7-inch 12G-SDI field monitor. Please read this manual carefully before using the unit. Have a great experience!

Caution

- 1. Please avoid the heavy impact and drop onto the ground when move the product.
- 2. The screen of this product is made of glass.Keep away from injury if the screen is broken.
- 3. Keep the product away from the heat source, and avoid the prolonged exposures to the sun as the LCD screen will be damaged.
- Please do NOT use chemical solutions to clean this product.
 Please wipe the monitor with a clean soft cloth to maintain the brightness of the surface.
- 5. No adjustable components are in the monitor. Please do not take apart or repair the unit by yourself, to avoid the damage of the product.

Key Features

- •7-inch 1920x1200 full HD IPS screen
- Touch screen menu operation, improve shooting efficiency
- 1600nits daylight viewable
- Rugged aluminium housing
- 12G-SDI input and output, meet more professional production
- With SDI & HDMI cross conversion
- Support HDR monitoring, what you see is what you get
- Support 3D LUT Log to REC.709 and user 3D LUT upload(up to 32)

- 3G-SDI & HDMI support LUT loop out
- With Waveform, Vector scope, Histogram, Focus Assist, Monochrome etc. functions, can help you accurately exposure and focus every shot.
- Under HDMI signal the audio meter level can be display max 8 channels; under SDI signal can be display max.16 channels
- Tally Indicator, enhance team cooperation
- Stereo Earphone output
- Standard accessory F970 dual battery plates, long-lasting power for outdoor filming

CONTENTS

1. Product Description4
1.1 Structure Instruction 4
1.2 Power Supply Ways 4
1.3 Battery Plate Mount Steps 5
1.4 Mount Points 6
1.5 TALLY Indicator Connection7
2. Menu Operation Instruction7
2.1 Touch Screen Menu Operation7
2.2 MENU Wheel Menu Operation 8
2.3 MENU UI Instruction9
2.4 Cross Conversion Instruction9
3. Menu Function Instruction 10
4. How to Load LUT 18
5.Custom LUT Calibration Instruction 19
6. Support Formats 20
7. Technical Parameters 21
8. Trouble Shooting 22

1. Product Description

1.1 Structure Instruction



Battery Plate

Tally Signal Input

1.2 Power Supply Ways

(1) The rear cover of the monitor is equipped with a dual F970 battery plate, which is applicable to F970 series of batteries. The battery level will be showed on the right upper corner of the monitor after the battery installation. The user also can select V-mount battery plate for option.

Sony F970 battery plate for battery of Sony DV:

Sony F970 F960 F950 F930 F770 F750 F730 F570 F550 F530 series

Remark: It is recommended to use standard original F970 batteries. Different specifications of the battery have different capability. The working time for the monitor will be different. Higher capability (working time) will be longer. Please take off the battery from the monitor if you don't use the monitor in a long time.

Battery Switching Instruction: When install two batteries at the same time, both battery level will be showed on the right upper corner of the monitor. Users can click on another battery to switch when one battery is running low, the white indicating working battery and the gray indicating non-working battery.

(2) DC IN 12V: DC power input, polarity as the input power - +, Barrel
(5.5mm outer, 2.1mm inner) at the bottom of the monitor, DC 7~24V Input.
Suitable use for 12V/1.5A or 2A power adapter.

1.3 Battery Plate Mount Steps

- (1) Install the 2P power cable to the cutout
- (2) Align the screws with the screw holes and tighten them



5

✤ Picture after battery plate installation



1.4 Mount Points

There are (3) $\frac{1}{4}$ -20 thread points (bottom, right , left) can be easily connected to the hot shoe mount, tripod fixed installation.



1.5 TALLY Indicator Connection



Indicator Color	Pin connect
Green	1-5
Red	6-5
Yellow	9-5

2. Menu Operation Instruction

After the monitor is properly connected to the power supply, the button display(red indicating). Long press button to turn on the monitor and turns yellow indicating. After the signal is connected, the button turns green indicating.

2.1 Touch Screen Menu Operation (turn on the screen touch function)

- The touch function can be set as a shortcut key via Menu -User Option --Shortcut Key - -F1, F2 or F3- -Touch Switch. When the menu is not displayed, you can press it directly turn on or off the touch function. For example, you set it as F1, please press F1
- ②. Double-click on the screen to open the main menu (show on the left side of the screen) and click on the corresponding menu to display the secondary menu. You can enter the corresponding function option and click directly to select or set. Click the touch screen to exit the menu.
- ③. When the menu is not displayed, swipe up from the bottom of the screen to open the shortcut menu, swipe left or right select the needed function and click on the corresponding menu box to turn on or turn off the corresponding

function. (remark: the shortcut menu can't set the detail function or parameters, you can set on main menu)

④. When the menu is not displayed, on the left side of the screen (1/2 split screen), you can directly adjust the brightness of the screen backlight; on the right side of the screen (1/2 split screen), you can directly adjust the volume.

Figure:



2.2 MENU Wheel Menu Operation

- When the menu is not displayed, directly rotate the wheel to backlight or volume adjustment. The wheel option can be set to backlight or volume via menu ______--left right key
- ②. Short press the MENU wheel to open the main menu (on the left side of the screen), rotate the wheel to select menu. After selected, press the wheel to show the secondary menu, then rotate the wheel to select. After selected, press the wheel to enter function menu, rotate the wheel to select or set option function, press the wheel to confirm after selected or set, then the icon will show gray.

- ③. Long press the MENU wheel to open the shortcut menu (below the screen), rotate the wheel to select the shortcut menu option, press the wheel to directly turn on/off the function.
- ④.Press F3/EXIT key to return or return the menu

2.3 MENU UI Instruction



2.4 Cross Conversion Instruction

The monitor supports SDI and HDMI signal cross conversion, the output resolution support max.1920x1080

- HDMI input can output HDMI, 3G-SDI simultaneously
- 12G-SDI input can output HDMI, 3G-SDI ,12G-SDI simultaneously

Note: (1) when use the cross conversion function, the HDMI output need to set as **Display** (enter main menu **System--Source--Output Source--HDMI OUT--Display**) (2) the support format of 12G-SDI output always same as 12G-SDI input

3. Menu Function Instruction

Assist	
	ON, OFF
الملال شم	After turning on, waveform, vector, histogram and embedded
All Waves	audio will be shown.
	ON, OFF
	Mode: RGB, YUV, Y
	Waves Trans.:Off, 25%,50%,75%
	Position X: 0~100 (moving the waveform horizontally)
Waveform	Position Y: 0~100 (moving the waveform vertically)
	This essential feature assists with the calibration of
	professional video cameras. It shows the overall brightness of
	the image assisting the video professional in correcting
	exposure. The waveform feature also checks the evenness of
	the lighting when lighting a chromakey or background.
	ON, OFF
<u></u>	Position X: 0~100 (moving the Vector horizontally)
	Position Y: 0~100 (moving the Vector vertically)
Vector	Shows how saturated the image is and where the pixels in the
	image land on the color spectrum.
	ON, OFF
6	Mode: RGB1, RGB2, Y
	Position X: 0~100 (moving the histogram horizontally)
Histogram	Position Y: 0~100 (moving the histogram vertically)
	Y Histogram
	A quantitative tool to check the picture brightness, display
	different color for different brightness
	RGB Histogram

	It can display the graphic of color tone distribution, can
	intuitively display the exposure status of the image, and display
	overlapping histograms in red, green, and blue channels
	ON, OFF
	Color: Red, Green, Blue
	Peaking Level: 1~10
Focus Assist	After turned on, the Focus Level (1 \sim 10) and Focus Color
	can be adjusted.
	It highlights the areas that are in focus so you are able to
	quickly focus the camera and not miss crucial shots.
	ON, OFF
	Display an audio diagram after enabled to help you understand
<u> </u>	the audio status being used.
Embedded Audio	Under HDMI Signal, max display 8 channels
	Mode: pr1, gp1, gp2, gp12
	Audio Out: ch1-2, ch3-4, ch5-6, ch7-8
	pr1 display1-2 channel, gp1 display 1-4 channel, gp2 display
	5-8 channel, gp12 display 1-8 channel
	Under SDI Signal, max display 16 channels
	Mode: pr1, gp1, gp2, gp12, gp3, gp4, gp14
	Audio Out: ch1-2, ch3-4, ch5-6, ch7-8, ch9-10, ch11-12,
	ch13-14,ch15-16
	pr1 display1-2 channel, gp1 display 1-4 channel, gp2 display
	5-8 channel, gp12 display 1-8 channel, gp3 display 9-13
	channel, gp4 display 14-16 channel, gp14 display 1-16 channel
	Display an audio diagram after enabled to help you understand
	the audio status being used.
	Position X: 0~100 (moving the audio level horizontally)
	Position Y: 0~100 (moving the audio level vertically)
	ON, OFF
	After the experience is turned on the Experience level (400E -

After the exposure is turned on, the **Exposure Level (10RE** \sim

Over Exposure	100IRE),, can be adjusted.
ി	On, Off
	Mode: red, green, blue, gray
Check Field	When enabled, hue and saturation adjusted quickly and
	accurately.
	ON, OFF
	Mode: Normal, ARRI
	An image that depicts an object in colors that differ from those
False Color	a photograph (a true color image) would show.



	ON, OFF Mode: 2x2. 3x3. 4x4. 5x5. 6x6. 7x7. 8x8. 9x9.
	Custom
	Custom
Grids	Rows: 2~9
	Columns: 2~9
	When selecting Custom , you can custom the rows and
	columns of the grid
	Color: Red, Green, Blue, Black, White, Gray
	The area of the picture can be divided into 4,9, 16, 25, 36,
	49,64,81 equal grids or custom the grid.
	OFF, ON
	Mode: 80%, 85%, 90%, 93%, 96%, 2.35:1
Safe Frames	Marker Line Color: Red, Green, Blue, Black, White, Gray
	ON, OFF
	Marker Line Color: Red, Green, Blue, Black, White, Gray
Center Marker	
	ON, OFF

Ratio Marker	Mode: 4:3, 13:9, 14:9, 15:9, 16:9, 1.85:1, 2.35:1
	Marker Line Color: Red, Green, Blue, Black, White, Gray
	Modified Mark: 0~5



F Scan Mode	Under Scan, Over Scan
Aspect Ratio	Auto, 16:9, 16:10, 4:3, 5:4, 1.85:1, 2.35:1, Full Screen
	ON, OFF Mode: 1.33x, 1.6x, 2.0x, 2.0x mag, User
Anamorphic	Under User, you can custom adjust nx (1.20x~2.00x) Allows you to use anamorphic lenses or adapters and see the image unsqueezed, even if your camera does not de-squeeze in camera
Image Flip	ON, OFF Mode: H Flip, V Flip, H_V Flip
(O	ON, OFF Mode: 2X, 4X, 9X, 16X, User Under User, you can adjust 100%~200%
Zoom Mode	It is HD signal in any part, an amplification for high quality close-up.
Image Freeze	ON, OFF
	ON, OFF

	Enable the filmmaker to check the image from the 1:1 signal
P2P	source without scaling. This feature is essential for capturing
(Pixel to Pixel)	optimum detail.



	ON, OFF
\bigcirc	LUT is a table for quickly looking up and output specific color
	data. By loading different 3D-LUT tables, it can quickly
LUT	recombine color tone to form different color styles.
	LUT Import: Confirm
	LUT Table: display built-in SLOG2, SLOG3, LOGC,
	VLOG and the custom LUTs
	HDR: ON, OFF
HDR	Mode: HLG1, HLG2, HLG3
	HDR can provide more dynamic range and the details of
HDR	image, it is better to reflect the visual effects in the real
	environment.
	Backlight: 0~100
	Adjust the screen brightness
	Brightness: 0~100
	Adjust the image brightness
Display Adjustment	Contrast: 0~100
	Adjustment of the ratio between the brightest and darkest
	parts of the image . When adjusting, pay attention to the
	sense of hierarchy in the image. If the proportion is too large
	or too small, it can cause the image to lose its colorful
	appearance.

	Saturation: 0~100
	Adjustment of color concentration
	Tint: 0~100
	It is the most accurate standard for distinguishing various
	different colors. Determine what a certain color is actually
	color via the color appearance.
	Color Gamut: DCI-P3, REC709
	Display Range: Auto, Limit, Full
Color Adjustment	This feature allows for the selection of a grayscale range.
	The Limited grayscale range is 16-235, and the Full
	grayscale range is 0-255. (Grayscale represents changes in
	image brightness, using varying gray levels to depict
	brightness in different image areas. In grayscale, brightness
	increases from black to white, typically denoted by a
	numerical range from 0 to 255, where 0 signifies black and
	255 indicates white, and intermediate numbers indicate
	varying grayscale levels.)
	1. If the dark part of the picture lost, the details cannot be
	seen clearly. For example, the input signal is in the range of
	0-255, but the monitor is set Auto or Limit, the brightness of
	0-15 and 236-255 is removed, resulting the dark part details
	unclear. You can set to Full.
	2. If the picture is gray, the black part turned gray. For
	example, the input signal is in the range of 16-235, but the
	monitor is set Full , resulting the black part turn gray. At this
	time,you can set to Auto or Limit.
	Color Temp.: 5600K, 6500K, 9300K, User
	Under the " user ", the red . areen , and blue values of the
	image can be adjusted ($0 \sim 255$)

	F1~F3
F Shortcut Key	Shortcut List: All Waves, Waveform Vector, Histogram,
	Embedded Audio, Center Marker, Safe Frames, Grids, Focus
, , , , , , , , , , , , , , , , , , ,	Assist, False Colors , Over Exposure, Anamorphic, Image
	Freeze, Check Field, Zoom Mode, Image Flip, Aspect Ratio,
	Touch Switch
	Set the shortcut function
	e.g.: Tap the Shortcut Key in User Option, and select
	F1 Function, then select one of function on Shortcut List,
	such as "Analysis". So when you exit menu, you could press
	F1 directly on the front of panel to turn on "Analysis" function.
	Same setting for F2~F4
	Backlight, Volume
Left Right Key Set	



	English, 简体中文, Español, Português, Français,		
Language	Nederlands, Deutsch,日本語, 繁體中文, 한국어로,		
	русский язык		
020	OSD Time: off, 15s, 30s, 45s		
	Select the display time of the menu on the screen		
OSD Option	OSD Trans: OFF, 25%, 50%, 75%		
	Adjust the transparency of the menu picture background on		
	the screen.		
	No Signal: Red, Green, Blue, Black, White, Gray		
()	Mute: ON, OFF		
	Volume: 0~100		
Volume	Adjusting the speaker volume		

	ON, OFF		
S	Mode:1~5		
Cooling Fan	Note: the fan default to ON and with 3 mode		
	Input Source: HDMI, SDI		
চি	Output Source		
رتنج	HDMI OUT: Loop Out, Display		
Source	When selecting Loop Out, HDMI output supports up to 4K@60Hz;		
	When selecting Display , it defaults to output with LUT effect and		
	supports maximum resolution of 1920x1080. When you need to		
	use cross conversion , please also select Display.		
	3G-SDI LUT Out: LUT On, LUT Off		
C			
	After confirmed, the system back to original setting.		
Reset			
	Firmware Version (display the current firmware version)		
↑	FTY CAL: On, Reset		
	Reset: If you import your own LUT calibration but encounter		
	abnormalities or poor result, you can clear the calibration LUT		
Firmware Update	by clicking "Reset" in FTY CAL and return to the factory		
	calibration.		
	Confirm		
	Each monitor has color calibration before ex-factory, the		
	factory calibration button turn on by default. After turning off,		
	the monitor will without has color calibration, suggest don't		
	turn it off		
	How to upgrade?		
	1. SD card format		
	Support FA132 or N1FS. For MAC system, the SD card		
	should be formatted in MS-DOS (FAT)		
	2. After copying the update file to the SD card and inserting it		

into the SD card slot, click Confirm to update.
3. The monitor will turn off automatically after finishing, please
turn on manually
4. Check the firmware version whether the latest one
Note: the chip should be faced up when inserting the SD
card, and press it after inserting to ensure that the SD card is
fully inserted.

4. How to Load LUT

4.1 SD card format

Support FAT32 or NTFS. For MAC system, the SD card should be

formatted in MS-DOS (FAT)

4.2 Max Files Limit Maximum 32 Lut files

4.3 File requirements

- The LUT file format suffix should be .cube
- Single file not exceeded to 7.9Mb
- Support LUT-3D-Size 16,17,32,33,64,65

Remark: LUT file name must be English or Arabic numerals

4.4 Steps for loading

4.4.1 Make sure the SD card correctly insert

4.4.2 Enter main menu "User Option" -- LUT -- Lut Import -- Confirm to load

the monitor will auto detect the SD card

A. There is no SD Card, the screen will show failed, can try once more, if not work, restart the monitor and try again

B. There is SD Card, the monitor will erase the exits user's lut fill and show "Initializing", If there is no valid lut file in SD card, the lut will not load. The monitor will show "clean up"

C. If there is valid lut file in SD card, the monitor will load lut files and show "[n] name. The [n] shows the quantity number. The "name" should in lut files' name. If load successful, the screen will show "complete[n]". [n] Stands for the quantity number for lut files should under 32.

5. Custom LUT Calibration Instruction

If you have professional equipment and instrument and want to calibrate the monitor by self. Please take note the following points:

5.1 SD card format

Support FAT32 or NTFS. For MAC system, the SD card should be formatted in MS-DOS(FAT)

5.2 File requirements

- The LUT file format suffix should be .cube
- Single file not exceeded to 7.9Mb
- Support LUT-3D-Size 16,17,32,33,64,65
- For P3 color calibration, file name should be @User_P3xxxx.cube, the red font can't be changed, the xxxx can be custom. For example, @User_P3_123456789.cube
- For 709 color calibration, file name should be $@User_709xxxx$. cube, the red font can't

be changed, the xxxx can be custom. For example, @User_709_abcdefg.cube.

5.3 Steps for loading

5.3.1 Make sure the SD card correctly insert

5.3.2 Enter main menu "User Option"--LUT--Lut Import -- Confirm to load

the monitor will auto detect the SD card

5.3.3 After loading, the file will show like below

HDM 1920x1080	00860Hz		LUT Off	
Assist	Canguage	Firmware Version V	/1.0.5 set	
Marker	OSD OSD Option	@User_P3_jd @User_709_jd	ytest1 ytest2	
image	Volume			
User option	Cooling Fan			
System	Source	Confirm		
	C Reset	-		
	Firmware Update			

5.4 If you import your own LUT calibration but encounter abnormalities or poor result, you can clear the calibration LUT by clicking "Reset" in FTY CAL and return to the factory calibration.

6. Support Formats

12G-SDI Input & Output Support Format	1080i (60/59.94/50) 720p (60/59 94/50/30/29 97/25/24/23 98)
	1080p(60/59.94/50/30/29.97/25/24/24sF/23.98/23.98sF) 2048×1080(30p/30PsF/29.97p/29.97PsF/25p/25PsF/24p/24PsF/23 .98p/23.98PsF) 4K 3840×2160p (60/59.94/50/48/47.95/30/29.97/25/24/23.98) 4K 4096×2160p (60/59.94/50/48/47.95/30/29.97/25/24/23.98)
3G-SDI Output Support Format	720p (60/59.94/50/30/29.97/25/24/23.98) 1080i (60/59.94/50) 1080p(60/59.94/50/30/29.97/25/24/24sF/23.98/23.98sF)
HDMI Input Support Format	1080i (60/59.94/50) 720p (60/59.94/50/30/29.97/25/24/23.98) 1080p(60/59.94/50/30/29.97/25/24/24sF/23.98/23.98sF) 4K 3840×2160p (60/50/30/29.97/25/24/23.98) 4K 4096×2160p (60/50/30/29.97/25/24/23.98)

	When set Display
	1080i (60/59.94/50)
	720p (60/59.94/50/30/29.97/25/24/23.98)
	1080p(60/59.94/50/30/29.97/25/24/24sF/23.98/23.98sF)
HDMI Output	When set Loop out (without set it will default to Loop out)
Support Format	1080i (60/59.94/50)
	720p (60/59.94/50/30/29.97/25/24/23.98)
	1080p(60/59.94/50/30/29.97/25/24/24sF/23.98/23.98sF)
	4K 3840×2160p (60/50/30/29.97/25/24/23.98)
	4K 4096×2160p (60/50/30/29.97/25/24/23.98)

7. Technical Parameters

Panel Size	7" touch screen
Resolution	1920 × 1200 pixels
Dot Pitch	26.25 (H) x 78.75 (W) (um)
Color Depth	10bit (8+2bit)
Aspect Ratio	16:10
Brightness	1600cd/m ²
Contrast	1200:1
Viewing Angle	80°/80°(L/R) 80°/80°(U/D)
Backlight	LED
Backlight Adjustment Mode	Manual
Input	12G-SDI, HDMI, Tally
Output	12G-SDI, 3G-SDI, HDMI
Audio	3.5mm Stereo Headphone
Power Input Voltage	7~24V
Power Consumption	≦16W
Unit Size	186*116.9*25 (mm)
Unit Weight	550g
Mount Points	(3) ¹ / ₄ -20 thread points (right, left, bottom)
Working Temperature	-10°C~60°C

8. Trouble Shooting

8.1 Only black and white or monochrome picture:

- ① please check saturation, brightness & contrast adjustment.
- 2 Please check "Monochrome" is in black, white or monochrome image or other condition.

8.2 NO Image after put on the power

- ① Check if signal cable connecting is in good condition.
- ② Check signal cable connecting, and make sure to use the standard adapter to connect the monitor. If power is supplied by battery, please check if the battery is fully charged.

8.3 Earphone No sound

- 1 Check if Volume control do not open, press the volume button, and try to increase the volume.
- If there are still other problems, please contact with our related technologists.
- ★ As we are improving product features and product performance, so if there is any change on the specification without prior notice.